# **New Delac**




- Multi-purpose rail with a wide range of applications.
- •Manual, cord draw and motor operation are possible.
- Exceptional durability satisfying the strict demands of a 10,000 open/close test.
- Can also be used as a hospital partition rail,
   IV rail and picture rail.
- It can be used for wavy styles that bring out the natural texture of the fabric.

# **New Delac**

# New Delac's Unique Features and Applications

# Using the Overlap MG Carrier for Hand provides better light shielding.


The Overlap MG Carrier effectively prevents unwanted light from streaming into a room. Light is kept out even where the curtains overlap in the middle. And the rollers run very smoothly.



\*Perfect light shielding may not be possible depending on the type of window and installation method. Please consult a specialist when designing window covering for a darkroom or photo lab.

#### Use an IV Roller for an IV Rail.

New Delac's exceptional durability and safety make it ideal for use as an IV Rail in hospitals and other medical institutions. The IV Rollers are also designed to lock under the weight of an IV bottle. And the wheel parts are made of a special resin to effectively reduce sliding noise.




# **Smart Wave Curtain System**


### [Invisible Pitch Keeper Tape]

By connecting the roller and the pitch keeper tape, it can create a beautiful curtain wave.

The pitch keeper tape fits inside the track for a clean look.



# **Wave Style**




- The Wave Style creates a feeling of naturally flowing fabric.
- The curtains are draped in gentle waves about 1.5–2.2 times the width of window, resulting in a continuity of pattern and texture.
- There is a natural wave in the curtains at intervals of 80 mm (3.2").
- With its tape and accessories, it creates natural, elegant symmetrical waves.
  - \*Pleating cord keeps waves evenly shaped, making the curtain rich and stylish.
- \*For more details about Wave Style, please refer to the catalog "New Delac with Wave Style Components".



# NT Bracket convenient when there is insufficient vertical space for installation.

This bracket is convenient when there is insufficient vertical space for bracket installation.


It is firmly secured with just two screws.



# Brackets with a temporary hook makes installation easier.

### (Excluding Extra Brackets)


This bracket holds a rail while allowing you to adjust a rail position. Once you finish adjusting a position, simply snap the rail into the bracket to secure firmly.



# Smooth opening and closing with separate grooves for rollers and traverse cord.

Installation is easy and the cord is located in a groove to prevent it from becoming entangled with the rollers.

The smooth-running rollers also assure easy opening and closing.




# Partitioning is flexible, by using the Last-in Intermediate Stop


Last-in Intermediate Stop is usable both fix and open/close the curtain.



Last-in Intermediate Stop



Curtain hook is fixed by turning the hole toward the front.



When the hole is turned sideways, MG Carrier can be attracted.

# Can also be used with a Curtain Motor. (Powerful Series)

Exceptionally convenient for opening and closing wide curtains, curtains installed in a high location, and heavy curtains.



# New Delac Rails



0:		Product Code				
	Size	Silver	Umber	Black	White *1	Warm white
1.82 m (72")		00210120	00210036	30010561		00210226
2.00 m (79")		00210121	00210038	30010562		00210227
2.73 m (107")		00210122	00210039	30010563		00210228
3.00 m (118")		00210123	00210040	30010564		00210229
3.64 m (143")		00210124	00210047			00210230
4.00 m (157")		00210125	00210048			00210231
Curved Rail	0.40 m × 0.40 m (16" × 16")	00210126	00210045	30010565		00210232
(180 mmR / 7.1"R)	1.00 m × 1.00 m (39" × 39")	00210035	00210046	30010566		00210233
Overlap Rail 0.50 m (20")		00210208	00210043	30010567		00210234


<sup>\*1</sup> For the White, please inquire of TOSO.

### Materials and Finishes

	Parts	Material	Finish
	Silver	Aluminum alloy extrusion material	Alumite
	Umber		Alumite umber
Rail	Black		Alumite black
	White		Alumite white
	Warm white		Alumite warm white

Parts		Material	Finish
	Plate	Hard polyethylene	
Roller	Wheel	Hard polyethylene	
	Oval ring	Stainless steel	
End Cap	Body	Nylon	
Eliu Cap	Oval ring	Stainless steel	
Bracket	Body	Steel	
	Hook	Acetal resin	

# Bracket Installation Interval and Allowable Curtain Load




### Installation Dimensions

#### Ceiling Attachment


### Direct attachment

Ceiling Single Bracket Bracket width = 18 mm (.71") 57 mm (2.2") 45 mm (1.8") 31 mm 35 mm (1.2'')(1.4'')15 mm 15 mm 22.5 mm (.59'')(.59")

#### Ceiling Double Bracket Bracket width = 18 mm (.71")




#### Extra Ceiling Double Bracket Bracket width = 23 mm (.91")




#### Wall Attachment

(.89")


Single Bracket Bracket width = 19 mm (.75")




#### Double Bracket Bracket width = 19 mm (.75")




#### Extra Double Bracket Bracket width = 25 mm (.98")




#### Extra Single Bracket




### NT Double Bracket





### Overlap Rail



# New Delac Parts

	Product Name Product Code			
	Roller		1 Toduct Code	
	(8 pieces per strip)	Natural	00210027	
	MG Carrier	Natural	00210054	
	One-way MG Carrier	Natural	00210053	
	NN Roller (for last-in)		00210008	
	Noiseless Roller (8 pieces per strip)	Natural	00210188	
Rollers	Noiseless MG Carrier	Natural	00210189	
	Noiseless One-way MG Carrier	Natural	00210190	
	Soundproof Packing Silence effect improves together it with Noiseless Roller.		00210023	
	Overlap MG Carrier for Hand	(*1)	00210006	
	Carabiner Roller	Natural	30018426	

<sup>\*1</sup> For a curved rail, use with a rail with a radius of 240 mm (9.4") or more. A rail with a 180 mm (7.1") radius can not be used.

	Product Name Product Cod			
	Single Bracket	Silver	00210213	
	Single bracket	Umber	00210214	
		Black	30010574	
		White	00210324	
		Warm white	00210215	
	Extra Single	Silver	00210012	
	Bracket	Umber	00210084	
		White	30011802	
		Warm white	00210155	
	Double Bracket	Silver	00210216	
		Umber	00210217	
		Black	30010575	
		White	00210325	
		Warm white	00210218	
	NT Double	Silver	00210222	
	Bracket	Umber	00210223	
	O CO	Warm white	00210224	
	Extra Double	Silver	00210109	
	Bracket	Umber	00210082	
		White	30011801	
		Warm white	00210157	
cets	Ceiling Single	Silver	00210191	
Brackets	Bracket	Umber	00210192	
		Black	30010576	
		White	00210326	
		Warm white	00210193	
	Ceiling Double	Silver	00210219	
	Bracket	Umber	00210220	
		Black	30010577	
		White	00210327	
		Warm white	00210221	
	Extra Ceiling	Silver	00210107	
	Double Bracket	Umber	00210196	
		White	00210353	
		Warm white	00210197	
	Overhead Hanger	Silver	00210105	
		Umber	00210198	
		White	30010578	
	$\sim$	Warm white	00210199	
	Wall Bracket	Silver	00210015	
	~	Umber	00210201	
		Black	30010579	
	P	White	00210331	
		Warm white	00210202	
		I .		

	Product Name		Product Code
	End Cap	Natural	00210010
	Liid Cap	Umber	00210086
		Black	30010572
	End Stop B	Natural	00210135
	Lind Stop B	Umber	00210137
		Black	30010573
	r8.	White	30011800
		Warm white	00210200
	Last-in Intermediate		002.0200
End Caps	18	mm (.71")	30009046
	Intermediate Stop		
			00210134
	Return Aids for End	Stop	
	Q		00530063
	Pulley Set	Silver	00210002
		Umber	00210081
		White	00210333
	<u> </u>	Warm white	00210159
Cord Draw Parts	Master Roller	00210262	
	Long Master Roller  100 mm (3.9")	mm (3.6") .6")	00210264
	One-way Master Ro	00210001	

Product Name				Product Code	
	Overlap Co		Kit		
	OVERAP OF			00210225	
			(*1)		
/ Parts	Traverse Co 2.8 mm DIA		White	00580009	
Cord Draw Parts	Tension Pu	lley 240	White	00500005	
0			Brown	00500002	
	Tension Pu	lley 450	Silver	00500007	
Other Parts	Splice for A	luminum R	ail	00210128	
Other	OT Splice		Silver	00210024	
			White	00210323	
	Adjustable Hanger Rod A	A170 (130–170 mm/ 5.1–6.7")	Silver	00290034	
			White	00290038	
			Black	30018783	
		A250 (170–250 mm/ 6.7–9.8")	Silver	00290036	
			White	00290039	
		0.7-3.0 )	Black	30018782	
	en de	A400	Silver	00290017	
		(245–400 mm/ 9.6–16")	White	00290040	
		0.0 10 )	Black	30018781	
		A700 (395–700 mm/ 16–28")	Silver	00290016	
			White	00290041	
			Black	30018797	
m		A1100	Silver	00290015	
r Parts		(595–1,100 mm/ 23–43")	White	00290042	
er F		20-40 )	Black	30018789	
Othe		A1600	Silver	00290014	
		(845–1,600 mm/ 33–63")	White	00290043	
			Black	30018786	
	Adjustable Hanger	B400 (250–400 mm/	Umber	00290013	
	Rod B	9.8–16")	White	00290026	
		B700 (400–700 mm/ 16–28")	Umber	00290012	
	- I	10-20 )	White	00290025	
	IV Roller	10 kg (22 lb)		00210052	
	/				

<sup>\*1</sup> Contents of Kit: Overlap Pulley Set (1 set), Pilot Roller (2 pcs), Overlap Bracket (1 pc), Intermediate Stop (4 pcs), Cord Clip (10 pcs)

# New Delac Parts Wave Style Dedicated Parts (Cord Type)

	Product Name	Product Code
Roller	New Delac Wave Roller (2,000 pcs)	30019113

	Product Name	Product Code
Other Parts	New Delac Pitch Keeper Cord 60 (200 m)	30019114
Other	New Delac Pitch Keeper Cord 80 (200 m)	30019115

# Smart Wave Curtain System Dedicated Parts

	Product Name	Product Code
	Smart Wave Roller	30018621
Rollers	Smart Wave MG Carrier	30018622
	Smart Wave One-way MG Carrier	30018623


Invisible Pitch Keeper Tape 80 (15 m)  Invisible Pitch Keeper Tape 80 (50 m)  Invisible Pitch Keeper Tape 60 (50 m)  Curtain Stopper  Wave End Cap  Natural  Black 30018808  Black 30018809  Umber 30018810		Product Name	Product Code	
Tape 80 (50 m) 30018625  Invisible Pitch Keeper Tape 60 (50 m) 30019302  Curtain Stopper 30018807  Wave End Cap Natural 30018808  Black 30018809		Tape 80	2	30018624
Some Some Some Some Some Some Some Some	Parts	Tape 80 (50 m)	2	30018625
30018807  Wave End Cap  Natural 30018808  Black 30018809	Other	Tape 60	30019302	
Black 30018809		Curtain Stopper		30018807
	Ь	Wave End Cap	Natural	30018808
	nd Ca		Black	30018809
	Ш		Umber	30018810




#### Curtain Wand

To keep the Wave Style, the New Delac is available with a Curtain Wand that attaches to the leading MG Slider. It is easy to operate high curtains and thick/heavy curtains, and prevents stains and wrinkles because the curtain fabric is not directly touched.

#### Curtain Wand / White (steel)



#### Curtain Wand / Crear (resin)



# Curtain Wand White and Clear are SIAA safety standards compliant for antiviral performance. It reduces the number of specific viruses on the product.

The SIAA mark is displayed on products that have been evaluated according to the ISO 21702 and ISO 22196 methods, and whose quality control and information have been disclosed under the Antimicrobial Product Technology Council guidelines.


#### Anti-virus processing

- •This product is not a pharmaceutical product.
- •It uses antiviral materials that meet the safety standards of SIAA.
- •This product conforms to SIAA safety standards.
- •Antiviral processing is not intended to treat or prevent diseases.

#### Antibacterial processing

- •This product is not a pharmaceutical product.
- It does not inhibit the growth of all bacteria.
- This product uses antimicrobial materials that meet SIAA safety standards.

#### Curtain Wand / Gray (rope type)




#### How to Use the Curtain Wand



Photo is the White (steel).

#### How to Install



Hook the fittings of the Curtain Wand to the oval ring of the MG Carrier.

\*If the MG Carrier has two oval rings, hook the Curtainhook to the first oval ring and the fittings of the Curtain Wand to the second oval ring.

#### Approximate Curtain Wand Length

Rail height position	2,200 -2,400 mm	2,000 -2,200 mm
Wand length	900 mm	700 mm

\*In case used by a person with a height of 155 cm