




# Creaty



- Speed Controller of Creaty Drum type prevents a rapid fall of the shades.
- Creaty Cord with a heart cam stopper offers an easy stop without swaying the cord.
- Twin shade systems are available both for Drum type and Cord type shades.

## Creaty Lineup

Drum Type		
Clutch		
Twin One Chain	Twin	Single
		
<p><b>Features</b></p> <ul style="list-style-type: none"> <li>• A single chain adjusts the front and back of both screens.</li> <li>• Easy and simple operation with one hand using the built-in Clutch.</li> <li>• The built-in Speed Controller prevents the screen from swooping down.</li> </ul>	<p><b>Features</b></p> <ul style="list-style-type: none"> <li>• Easy and simple operation with one hand using the built-in Clutch.</li> <li>• The built-in Speed Controller prevents the screen from swooping down.</li> </ul>	
<p><b>Allowable Size</b></p> <p>Width: 300–4,000 mm (12–158") Height: 480–4,000 mm (19–158")</p> <p>*Depending on the style. *If width is 390 mm (15") or less, height is up to 2,000 mm (79"). *If width is 400–660 mm (16–26"), height is up to 3,000 mm (118").</p>	<p><b>Allowable Size</b></p> <p>Width: 300–4,000 mm (12–158") Height: 480–3,000 mm (19–118")</p> <p>*Depending on the style. *If width is 390 mm (15") or less, height is up to 2,000 mm (79").</p>	<p><b>Allowable Size</b></p> <p>Width: 300–4,000 mm (12–158") Height: 480–4,000 mm (19–158")</p> <p>*Depending on the style. *If width is 390 mm (15") or less, height is up to 2,000 mm (79"). *If width is 400–660 mm (16–26"), height is up to 3,000 mm (118").</p>
<p><b>Maximum Shade Weight</b></p> <p>Up to 8 kg (18 lb) in total of 2 shades</p> <p>*Front and back shade, each one is up to 4 kg (9 lb).</p>	<p><b>Maximum Shade Weight</b></p> <p>Up to 8 kg (18 lb) in total of 2 shades</p> <p>*Either front or back shade is up to 5 kg (11 lb).</p>	<p><b>Maximum Shade Weight</b></p> <p>5 kg (11 lb)</p> <p>*Including sewing materials.</p>
<p><b>Allowable Style</b></p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  Plain + Plain         </div> <div style="text-align: center;">  Sharp + Plain         </div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;">  Sharp + Sharp         </div> </div>		<p><b>Allowable Style</b></p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  Plain         </div> <div style="text-align: center;">  Sharp         </div> <div style="text-align: center;">  Austrian         </div> <div style="text-align: center;">  Austrian (Bay window)         </div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;">  Balloon         </div> <div style="text-align: center;">  Balloon (Bay window)         </div> </div>
<p>Refer to page 5 and page 13 for details</p>	<p>Refer to page 6 and page 13 for details</p>	<p>Refer to page 6 and page 12 for details</p>




### What is Twin?

- A compact head rail with two shades fits neatly on the window frame and yet offers an easy operation.
- Two shades operate with only one Head Rail. A single unit for two shades reduces cost.
- Can be selected operation for right side, left side or both sides (excluding Twin One Chain).



#### Allowable Products

- Creaty Drum Type Twin One Chain
- Creaty Drum Type Twin
- Creaty Cord Type Twin

Drum Type	Cord Type	
Gear	Twin	Single
Single		
		
<p><b>Features</b></p> <ul style="list-style-type: none"> <li>Operates lightly with the built-in Gear.</li> <li>Lowering is simple: When the hand lowers the Ball Chain, the shade falls by the same distance.</li> <li>Suitable for big windows.</li> </ul>	<p><b>Features</b></p> <ul style="list-style-type: none"> <li>Suitable for narrow windows.</li> <li>Simple and smooth operability.</li> </ul>	
<p><b>Allowable Size</b></p> <p>Width: 300–4,000 mm (12–158") Height: 480–4,000 mm (19–158")</p> <p>*Depending on the style. *If width is 390 mm (15") or less, height is up to 2,000 mm (79"). *If width is 400–660 mm (16–26"), height is up to 3,000 mm (118").</p>	<p><b>Allowable Size</b></p> <p>Width: 180–2,400 mm (7.1–94") Height: 480–3,000 mm (19–118")</p>	<p><b>Allowable Size</b></p> <p>Width: 180–2,400 mm (7.1–94") Height: 480–3,000 mm (19–118")</p> <p>*Depending on the style.</p>
<p><b>Maximum Shade Weight</b></p> <p>8 kg (18 lb)</p> <p>*Including sewing materials.</p>	<p><b>Maximum Shade Weight</b></p> <p>Up to 8 kg (18 lb) in total of 2 shades</p> <p>*Either front or back shade is up to 5 kg (11 lb).</p>	<p><b>Maximum Shade Weight</b></p> <p>5 kg (11 lb)</p> <p>*Including sewing materials.</p>
<p><b>Allowable Style</b></p> 	<p><b>Allowable Style</b></p> 	<p><b>Allowable Style</b></p> 
<a href="#">Refer to page 6 and page 12 for details</a>	<a href="#">Refer to page 7 and page 14 for details</a>	<a href="#">Refer to page 7 and page 15 for details</a>



Creaty's Unique Features

■ Creaty Drum Type Twin One Chain

• Achieve a smoother operability by the improvement of the Pulley

Adjusts easily with one hand for greater user comfort.  
Moves more smoothly while lifting just as quietly and easily as before.

Benefits of Twin One Chain

- Even in a large window, easy and smooth operability in one hand.
- Lifting operation of the front and back Shades with one chain, easy-to-handle and excellent looking.



How to Pull up the Shade

Pull down the ball chain and release your hand at the position you want to stop the Shade.



How to Pull down the Shade


Pull down the ball chain about 2 cm again and release your hand, the Shade is lifted down to the bottom.

• One Chain Operation

Both the front shade and back shade can be raised and lowered by a single chain.




How to pull up the Front Shade



Pull down the front side of the Ball Chain.




How to pull up the Back Shade



Pull down the back side of the Ball Chain.




How to pull down the Front Shade



Pull down the front side of the Ball Chain and release it.

How to pull down the Back Shade




Pull down the back side of the Ball Chain and release it.


• Two-story Structure for Simple and Compact Design

The vertical placement of the front and back rails in a single unit greatly reduces depth.

The discreet gap between the window frame and shade relaxes the cramped feeling of a room.



Two-story Structure Twin Head Rail



■ **Crealy Drum Type Twin / Single**

• **TOSO's Unique Single-Point Recoiling Drum**

Enables a stable lift-cord reeling: taking up the lift cord at a single point without lateral swaying when lifting the screen.  
Allows the screen to be neatly folded.

• **One- or Two-sided Operation Available**



Crealy Drum Type **Clutch**



Drum Type Single / White



Drum Type Twin / Brown



Ball Chain  
Color Lineup

Crealy Drum Type **Gear**



Drum Type Gear Single / White



Drum Type Gear Single / Brown



Ball Chain  
Color Lineup

- Easy and simple operation with one hand functioning the built-in Clutch.
- The built-in Speed Controller prevents the screen from swooping down.
- A simple one-touch operation lowers the shade. The shade slowly lowers by itself to the lowest position.

- Operates lightly with the built-in Gear.
- Lowering is simple: When the hand lowers the Ball Chain, the shade falls by the same distance.

\*Crealy Drum type Gear is no application of the twin.

## ■ Creaty Cord Twin / Single

### • Simple and Easy Operation

Quite operation with small power.  
The screen stops at anywhere you want.  
Even if you pull the cord from any angle,  
one-stop and one-release is possible.




Cord Type Single / White



Cord Type Twin / Brown


A heart cam stopper enables smooth raising and lowering of the shade.

#### Ordinary Roman Shades



Ordinary Roman Shades require the cord to be pulled straight down for operation.

#### Creaty Cord



Creaty Cord's heart cam stopper makes it possible to pull the cord at any angle for stop and release operation.

Sewing Method and Components

• **RS Cord Adjuster S**

The Cord Adjuster in separating when force is applied. It can be easily restored even if it comes off.

**Safety Type**



• **RS S-shaped Ring for Cord S**

If a child's hand or head gets tangled in the cord, the cord detaches from the tape ring when force is applied. Installation with RS Cord Adjuster S will further reduce danger.

**Safety Type**



• **RS Loop Tape Detachable**

Easy removal and installation make it easier than ever to wash and care for the fabric. It has no hassle to remove the Lift Cord from the RS Cord Adjuster N and to level the shade.



The RS Loop Tape Detachable is integrally connected to the Lift Cord, RS S-shaped Ring, and RS Cord Adjuster N. No adjustment required after installation.




Before the Lift Cord had to be removed from the Ring and Cord Adjuster, which required adjustment after installation.

• **Cord Stop S**

A safety mechanism in the upper part of the operation cord (circled) Cord Stop S will detach to eliminate danger when force is applied.

**Safety Type**



\*Two pieces required for the Twin.



## Optional Materials

### • Head Rail Joint / Twin Head Rail Joint


Use the Head Rail Joint to easily carry large rails into a room in divided sections. Reassemble the sections in a few easy steps just before installing.

A Twin Head Rail Joint is also available.


The packing size is reduced to half that for large rails, for high portability.



Head Rail Joint



Twin Head Rail Joint



### Allowable Size


Product Name	Width	Hight	Maximum Shade Weight (Including sewing materials)
Creaty Drum Type Twin One Chain	2,010–4,000 mm (79–157")	480–4,000 mm (19–157")	8 kg (17.6 lb)
Creaty Drum Type Gear			8 kg (17.6 lb)
Creaty Drum Type Clutch			5 kg (11 lb)




### • Corner Return

Corner Return provides a useful function for twin shades in corner windows.

Corner Return widens the back side of the screen to block outside light by filling in the gap between the shades in the corners.




Front shade  
Back shade



Length of Return:  
45 mm (1.8")

Front shade  
Back shade



Product width (W)

Back shade (W+45 mm)

Head Rail

Return

Front shade (W)

Corner Return is impossible to attach on the operating side. Weight Bar length is the front or back Shade width.

• **Corner Separate**

One Roman Shade will also work in external or internal bay windows.  
Possible simultaneous operation for the left and right both Roman Shade.

For internal bay window



By one unit at the corner window

For external bay window




Head Rail part



Bottom part

Structural Drawing



Ceiling attachment only.  
Attachment at 90 degrees bending form for internal or external corner.

Measuring Method for Corner Windows

	Attachment for <b>the outside</b> of the window frame	Attachment for <b>the inside</b> of the window frame	Installation Dimensions
Internal bay window	<p>Room side</p> <p>Window</p> <p>Window frame</p>	<p>Room side</p> <p>Window</p> <p>Window frame</p>	
External bay window	<p>Room side</p> <p>Window</p> <p>Window frame</p> <p>Take measurements from room side, left side is L1, right side is L2. Base point of measurement is rear position of the Bracket.</p>	<p>Room side</p> <p>Window</p> <p>Window frame</p> <p>Take measurements from room side, left side is l1, right side is l2. Base point of measurement is front position of the Head Rail.</p>	

Allowable Size


Product Width			Product Height
Minimum size for one side	Minimum size for both sides	Maximum size for both sides	
300 mm (12")	600 mm (24")	4,000 mm (158")	480–4,000 mm (19–158")

Product height is less than 2,000 mm (79") for either product width is 390 mm (15") or less.

Product height is less than 3,000 mm (118") for either product width is 400–660 mm (16–26") or less.


Creaty Drum Type Single / Creaty Drum Type Gear Single

Product View and Parts Name



\* Use for Creaty Drum Type Single only.

It is possible to correspond also to the Bay Window by using the (19) Corner Joint.




Parts


- ① Head Rail
- ② Slide-in Velcro
- ③ Bracket
- ④ Pulley Set
- ⑤ Ball Chain
- ⑥ Ball Chain Joint \*
- ⑦ End Cap
- ⑧ Lift Cord
- ⑨ Coiling Drum
- ⑩ Clutch \*
- ⑪ Speed Controller \*
- ⑫ Cord Adjuster
- ⑬ Return (Bay window styles)
- ⑭ Guide Cord (Austrian)
- ⑮ Guide Cord End (Austrian)
- ⑯ Weight Bar (Plain, Sharp)
- ⑰ Weight Bar Cap (Plain, Sharp)
- ⑱ Weight (Balloon, Austrian)
- ⑲ Corner Joint (Bay window styles)

Brackets

Universal Bracket



Ceiling Bracket



Maximum Shade Weight

Creaty Drum Single: 5 kg (11 lb)  
 Creaty Drum Gear Single: 8 kg (18 lb)  
 Including sewing materials.

Allowable Size


Product height (H)	Product width (W)	300-390 mm (12-15")	400-660 mm (16-26")	670-4,000 mm (26-158")
480-2,000 mm (19-79")		○ (*1)	○	○
2,010-3,000 mm (79-118")		—	○	○
3,010-4,000 mm (119-158")		—	—	○ (*2)

\*1 For Coiling Drum Short only. \*2 For Coiling Drum Long only.

Allowable size for bay window


The number of multiple	Product width			Product height
	The min. width of one side	Total min. width of one side	Total max width	
2	300 mm (12")	700 mm (28")	4,000 mm (158")	480-3,000 mm (19-118")
3		1,210 mm (48")		
4		1,500 mm (59")		
5				

\*Operation possible angle of Corner Joint is 90° to 180°.




Installation Dimensions


Wall attachment (With Universal Bracket)



Ceiling attachment (With Universal Bracket)




Ceiling attachment (With Ceiling Bracket)




Creaty Drum Type Twin One Chain / Creaty Drum Type Twin

Product View and Parts Name


Drum type twin one chain



One-sided operation



Two-sided operation




Parts


- ① Head Rail
- ② Slide-in Velcro
- ③ Bracket
- ④ Pulley Set
- ⑤ Ball Chain
- ⑥ Ball Chain Joint
- ⑦ End Cap
- ⑧ Lift Cord
- ⑨ Coiling Drum
- ⑩ Clutch
- ⑪ Speed Controller
- ⑫ Cord Adjuster
- ⑬ Return (Only when specified)
- ⑭ Weight Bar
- ⑮ Weight Bar Cap
- ⑯ Keeper Plate
- ⑰ One Chain Pulley Set
- ⑱ Loop Ball Chain

Brackets

Universal Bracket



Ceiling Bracket



Maximum Shade Weight

Total 8 kg (18 lb)

One-sided operation, Two-sided operation:

Front shade or back shade is 5 kg (11 lb) or less, and total weight is 8 kg (18 lb) or less. Including sewing materials.

One chain:

Front shade or back shade is 4 kg (9 lb) or less, and total weight is 8 kg (18 lb) or less. Including sewing materials.


Allowable Size

Product width (W)	300-390 mm (12-15")	400-660 mm (16-26")	670-4,000 mm (26-158")
Product height (H)			
480-2,000 mm (19-79")	○	○	○
2,010-3,000 mm (79-118")	—	○	○
3,010-4,000 mm (119-158")	—	—	○


\*Product height is 3,000 mm (118") or less at One-sided or Two-sided operation.

Installation Dimensions


Wall attachment (With Universal Bracket)



Ceiling attachment (With Universal Bracket)




Ceiling attachment (With Ceiling Bracket)



Creaty Cord Type Single

Product View and Parts Name




Parts


- ① Head Rail
- ② Slide-in Velcro
- ③ Bracket
- ④ Stopper Case (Main unit)
- ⑤ Cord Guide (Cord Guide A/B)
- ⑥ Stopper Guide (width up to 290 mm)
- ⑦ End Cap
- ⑧ Lift Cord
- ⑨ Cord Stop
- ⑩ Cord
- ⑪ Safety Joint
- ⑫ Cord Adjuster
- ⑬ Return (Only when specified)
- ⑭ Weight Bar
- ⑮ Weight Bar Cap

Brackets

Universal Bracket



Ceiling Bracket




Allowable Size

Product width (W)	180 mm (7.1") to 2,400 mm (94")
Product height (H)	480 mm (19") to 3,000 mm (118")

Allowable size for bay window

The number of multiple	Product width			Product height
	The min. width of one side	Total min. width of one side	Total max width	
2	150 mm (5.9")	700 mm (28")	2,350 mm (93")	480–3,000 mm (19–118")
3		1,010 mm (40")		

\*Operation possible angle of Corner Joint is 90° to 180°.




Maximum Shade Weight

5 kg (11 lb)


Including sewing materials.

Installation Dimensions


Wall attachment (With Universal Bracket)



Ceiling attachment (With Universal Bracket)




Ceiling attachment (With Ceiling Bracket)




Creaty Cord Type Twin

Product View and Parts Name

One-sided operation



Two-sided operation




Parts


- ① Head Rail
- ② Slide-in Velcro
- ③ Bracket
- ④ Stopper Case (Main unit)
- ⑤ Cord Guide (Cord Guide A/B)
- ⑥ Stopper Guide (Width up to 290 mm)
- ⑦ End Cap (One-sided operation only)
- ⑧ Lift Cord
- ⑨ Cord Stop
- ⑩ Cord
- ⑪ Cord Separator (One-sided operation only)
- ⑫ Safety Joint
- ⑬ Cord Adjuster
- ⑭ Return (Only when specified)
- ⑮ Weight Bar
- ⑯ Weight Bar Cap

Brackets

Universal Bracket



Ceiling Bracket



Maximum Shade Weight

Total 8 kg (18 lb)


Front shade or back shade is 5 kg (11 lb) or less, and total weight is 8 kg (18 lb) or less. Including sewing materials.

Allowable Size


Product width (W)	180 mm (7.1") to 2,400 mm (94")
Product height (H)	480 mm (19") to 3,000 mm (118")

Installation Dimensions


Wall attachment (With Universal Bracket)



Ceiling attachment (With Universal Bracket)




















Ceiling attachment (With Ceiling Bracket)










Creaty Parts

Product Name			Drum Type				Cord Type		Product Code	
			Clutch			Gear	Twin	Single		
			Twin One Chain	Twin	Single	Single				
Head Rail (4 m)		White	—	—	○	○	○	○	04610001	
		Brown	—	—	○	○	○	○	30000995	
Head Rail Joint			—	—	○	○	—	—	30007484	
Drum Twin Head Rail (4 m)		White	○	○	—	—	—	—	04620001	
		Brown	○	○	—	—	—	—	30000996	
Twin Head Rail Joint			○	—	—	—	—	—	30007483	
Slide-in Velcro (50 m)			○	○	○	○	○	○	01320263	
Universal Bracket		White	—	—	○	○	—	○	04610002	
		Brown	—	—	○	○	—	○	30001003	
Ceiling Bracket		White	○	○	○	○	○	○	04610003	
		Brown	○	○	○	○	○	○	30001004	
Twin Universal Bracket		White	○	○	—	—	○	—	04620002	
		Brown	○	○	—	—	○	—	30001002	
End Cap		White	—	—	○	○	○	○	04610004	
		Brown	—	—	○	○	○	○	30000997	
Drum Twin End Cap		White	○	○	—	—	—	—	04620016	
		Brown	○	○	—	—	—	—	30001005	
RS Ball Chain TO-0748		Clear White	—	○	○	—	—	—	04610013	
		Clear Beige	—	○	○	—	—	—	04610014	
		Clear Brown	—	○	○	—	—	—	04610015	
		White	—	○	○	—	—	—	04610016	
		Beige	—	○	○	—	—	—	30001009	
		Brown	—	○	○	—	—	—	30001008	
RS Loop Ball Chain TO-0748		L=1000 mm	White	○	—	—	○	—	—	04610045
			Beige	○	—	—	○	—	—	30001073
			Brown	○	—	—	○	—	—	30001069
		L=1500 mm	White	○	—	—	○	—	—	04610046
			Beige	○	—	—	○	—	—	30001074
			Brown	○	—	—	○	—	—	30001070
		L=2000 mm	White	○	—	—	○	—	—	04610047
			Beige	○	—	—	○	—	—	30001075
			Brown	○	—	—	○	—	—	30001071
		L=2500 mm	White	○	—	—	○	—	—	04610048
			Beige	○	—	—	○	—	—	30001076
			Brown	○	—	—	○	—	—	30001072
Ball Chain Joint		White	—	○	○	—	—	—	04610017	
		Beige	—	○	○	—	—	—	04610036	
		Brown	—	○	○	—	—	—	04610037	

Product Name	Drum Type				Cord Type		Product Code
	Clutch			Gear	Twin	Single	
	Twin One Chain	Twin	Single	Single			
Clutch 	—	○	○	—	—	—	04610040
Coiling Drum 	○	○	○	○	—	—	04610006
Coiling Drum Short 	○	○	○	○	—	—	04610044
Coiling Drum Long 	○	○	○	○	—	—	30003588
Corner Joint for Drum Type 	Right	—	—	○	○	—	04610008
	Left	—	—	○	○	—	04610009
Pulley 	White	—	—	○	—	—	04610005
	Brown	—	—	○	—	—	30000998
Pulley N 	Right	White	—	—	○	—	30003369
		Brown	—	—	○	—	30003371
	Left	White	—	—	○	—	30003370
		Brown	—	—	○	—	30003372
Gear Type Pulley 	White	—	—	—	○	—	30005344
	Brown	—	—	—	○	—	30005345
Drum Twin Pulley 	Right	White	—	○	—	—	04620005
		Brown	—	○	—	—	30000999
	Left	White	—	○	—	—	04620006
		Brown	—	○	—	—	30001000
Drum Twin One Chain Pulley 	Right	White	○	—	—	—	30008423
		Brown	○	—	—	—	30008425
	Left	White	○	—	—	—	30008424
		Brown	○	—	—	—	30008426

Product Name			Drum Type				Cord Type		Product Code
			Clutch			Gear	Twin	Single	
			Twin One Chain	Twin	Single	Single			
Return 45 mm 			<input type="radio"/>	04610011					
Adjustable Return 70–110 mm 			<input type="radio"/>	04610012					
Shaft 	3 m	Steel	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	—	04610018
	4 m	Steel	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	—	04610041
Speed Controller N 			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	—	—	30001920
Speed Controller N (Heavy duty) 			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	—	—	—	30001938
(*1) Cord Stopper 			—	—	—	—	<input type="radio"/>	<input type="radio"/>	04750002
Stopper Case 	White		—	—	—	—	<input type="radio"/>	<input type="radio"/>	04750004
	Brown		—	—	—	—	<input type="radio"/>	<input type="radio"/>	30001001
Cord Guide 			—	—	—	—	<input type="radio"/>	<input type="radio"/>	04750006
Cord Separator 			—	—	—	—	<input type="radio"/>	—	04750008
Corner Joint for Cord Type 	Right		—	—	—	—	—	<input type="radio"/>	04750010
	Left		—	—	—	—	—	<input type="radio"/>	04750012
Stopper Guide 			—	—	—	—	<input type="radio"/>	<input type="radio"/>	04750014
(*2)									







Product Name		Drum Type				Cord Type		Product Code
		Clutch			Gear	Twin	Single	
		Twin	One Chain	Single	Single			
Lift Cord (1.2 mm) TO-0712 	White	○	○	○	○	○	○	01320275
	Beige	○	○	○	○	○	○	01320276
	Brown	○	○	○	○	○	○	01320277
	Gray	○	○	○	○	○	○	01320278
RS Cord 2.8 mm 	White	—	—	—	—	○	○	01320231
	Beige	—	—	—	—	○	○	01320232
	Brown	—	—	—	—	○	○	01320234
	Gray	—	—	—	—	○	○	01320233
Cord Stop S 		—	—	—	—	○	○	30007495
RS Cord Stop N 	White	—	—	—	—	○	○	01320283
	Beige	—	—	—	—	○	○	01320285
	Brown	—	—	—	—	○	○	01320287
	Gray	—	—	—	—	○	○	01320289
RS Cord Stop Washer (*3) 		—	—	—	—	○	○	01320291
Creaty Cord Safety Joint (Large) 		—	—	—	—	○	○	30008427
RS Keeper Plate 		○	○	—	—	—	—	01320294
RS Weight Bar 250 4000 mm 		○	○	○	○	○	○	01710022
(*2)								
Weight Bar Joint 		○	—	○	○	—	—	30007485
RS Weight Bar Cap 25 		○	○	○	○	○	○	01710023
RS Weight Flat Bar 2000 mm 		○	○	○	—	○	—	01320253
RS Weight Steel Bar L300 		○	○	—	—	—	—	01320293
RS Weight Steel Bar L120 		○	○	—	—	○	○	01320295
(*2)								

\*1 Using for product width 1,410 mm (56") over.

\*2 Using for product width at 180 mm (7.1") to 290 mm (11.4").

\*3 Using for one swag.

Sewing and Optional Materials

Product Name	Style					Example of use amount	Product Code
	Plain + Plain	Plain	Sharp	Balloon	Austrian		
RS Tape with Loop 200 mm pitch (100 m) 	<input type="radio"/>	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	(Product height +100 mm) X (Number of swag +1) <sup>(*1)</sup>	01320261
RS Tape with Loop 150 mm pitch (100 m) 	<input type="radio"/>	<input type="radio"/>	<input type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	(Product height +100 mm) X (Number of swag +1) <sup>(*1)</sup>	01320109
RS Loop Tape Detachable (100 m) 	<input type="radio"/>	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	(Product height +100 mm) X (Number of swag +1) <sup>(*1)</sup>	30001116
RS S-Shaped Ring for Cord N 	<input type="radio"/>	<input type="radio"/>	<input type="checkbox"/>	<input type="radio"/>	<input type="radio"/>	Installation on RS Tape with Loop	01320273
RS S-Shaped Ring for Cord S 	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="checkbox"/>	Installation on RS Tape with Loop	30007032
Gather Tape DWI 75 (50 m) 	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="radio"/>	<input type="checkbox"/>	Same length of the shade width	02020002
Polyester Heading 75 mm (100 m) 	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="radio"/>	<input type="checkbox"/>	Same length of the shade width	00400064
RS Cord Adjuster R 	<input type="radio"/>	Number of swag +1 <sup>(*1)</sup>	30007112				
RS Cord Adjuster S 	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="checkbox"/>	Number of swag +1 <sup>(*1)</sup>	30007033
RS Velcro Tape Female (25 m) 	<input type="radio"/>	Same length of the shade width	01320108				
RS Shaper Tape (50 m) 	White	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Same length of the shade width	01320201
	Beige	<input type="checkbox"/>	<input type="checkbox"/>	<input type="radio"/>	<input type="checkbox"/>		01320198
	Brown	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		01320199
	Gray	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		01320200
RS Shaper Tape S 	White	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Same length of the shade width	30007034
	Beige	<input type="checkbox"/>	<input type="checkbox"/>	<input type="radio"/>	<input type="checkbox"/>		30007035
	Brown	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		30007036
	Gray	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		30007037
RS Shaper Rod 4000 mm 	<input type="checkbox"/>	<input type="checkbox"/>	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	Same length of the shade width	01320113
RS Twin Rings 	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Number of swag +1 <sup>(*2)</sup>	01320213

\*1 In the case of Plain + Plain, the required number doubles.

\*2 It is necessary only for Creaty Cord.